



CUSTOMER SERVICES BULLETIN

HOW TO CUT POLISH GELCOAT

Use Aqua-Buff products to remove scratches from and polish composite patterns, plugs, masters and molds. Also use them to remove scratches from and to clean FRP parts, metals and painted surfaces.

AQUA-BUFF 1000 FAST CUT COMPOUND

Spread Aqua-Buff 1000 on the surface to be compounded with a brush or cloth, several square feet at a time, and mist the surface with water. Immediately machine buff with a clean, damp compounding pad. Repeat the process to eliminate scratches from exceptionally hard surfaces. Should the compound become dry while being buffed, re-wet again by misting the surface with water. Follow with Aqua-Buff 200 Compound and Polish for the ultimate shine.

AQUA-BUFF 2000 COMPOUND AND POLISH

Spread Aqua-Buff 2000 Compound and Polish on the surface to be compounded with a brush or cloth, several square feet at a time, and mist the surface with water. Immediately machine buff with a clean, damp lamb's wool-type pad. Repeat the process to eliminate scratches from exceptionally hard surfaces. (Or if you haven't done so, first use Aqua-Buff 1000). Should the compound become dry while being buffed, re-wet again by misting the surface with water.

NOTE: For best results, use machine buffers that generate at least 2500 rpm for Aqua-Buff products.

COAST FIBER-TEK PRODUCTS LTD.

1306 Boundary Road, Burnaby, B.C. V5K 4T6
Phone: (604) 294-8116 Fax: (604) 294-8754

